

Hartman Products

Installation instructions

Install: “**Twist**” and push into hole or pipe.

Remove: “**Twist**” and pull out of hole or pipe.

Always “**TWIST**” plug when installing and removing. Can be installed with twisting motion clockwise or counterclockwise. As removal may not be by the same person that did the installation you may not know if the plug was installed with clockwise or counterclockwise twisting. If plug does not seem to want to twist in one direction then try the other direction.



Caution

DO NOT install the hole plug in holes that are not within the size range the hole plug is intended or indicated for.

Size range is indicated on top of hole plug and by corresponding color.